

Replaces Toro Greensmaster 3150-Q Parts



Brush Reel Unit - R&R Special Complete Brush Reel Unit





Replaces Toro Greensmaster 3150-Q Parts



Brush Reel Unit - R&R Special Complete Brush Reel Unit

Item R&ROEMQtyOrderNo Part No.Part No.DescriptionReq Quantity

Standard Brush Unit

1 **R150205**

Complete Brush Reel Unit

3

Tech Note: R&R Brush Reel Units complete with: R101480 Brush Reel, R94-6395 Thin Bedknife, R21-6540 Solid Front Roller & R21-8450 Solid Rear Roller:

Detail Description: R&R Products Brush Reels are great for greens maintenance to clean sand and other debris left on grass surfaces after top dressing. If left on the turf, this sand and debris cause dulling and excessive wear on mowing reels and bed knives. However, with the use of R&R Brush Reels, this sand and other debris is easily swept into conventional grass baskets.

R&R Brush Reels are also used to stand turf up before mowing to give a cleaner, more uniform, and truer putting surface.
Equipped with four replaceable polyethylene brushes mounted on a metal frame, simply replace regular mowing reels with R&R Brush Reels and adjust bed knives to clear the brushes. The height of cut should be set to the top of the grass blades or slightly below.
SBR>SUGGESTED SETTING
Normal Operation - Use bed knife with grass basket in place
Bed Knife to Brush Reel - 1/16 in to 1/8 in clearance
Brush Reel Height Adjustment - 1/32 in lower than cutting height
CBR>SUGGESTED USAGE
Verticutting
BR>Dew Removal
Leaf Cleaning Up
Thatch Prevention
Prior to Overseeding
BR>Grooming Before Mowing
Removal of Excessive Top Dressing:

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.